CDS-R

CDS-310R / N100



Maintenance, Operating & Service Manual

Bulroc [U.K.] LTD

ISOQAR REGISTERED

UKAS MANAGEMENT SYSTEMS 0026

Certificate No. 2448/00

LIST OF CONTENTS

CHAPTER	SECTION NO.
INTRODUCING THE *CDS310R* SYSTEM	
INDEX	**1**
INTRODUCTION	**1**
USING THE CDS310R	**2**
DRILLING WITH THE *CDS310R* SYSTEM	
CALCULATING THE LENGTHS FOR STARTER CASINGS	**3**
CASING SHOE SIZES	**3**
SYSTEM PARAMETERS	**3**
PARTS LIST FOR THE CDS310R	**4**
SERVICING	**5-6**
HOW THE SYSTEM WORKS	**7**
REFURBISHING WORN EQUIPMENT	
RING BIT & SEGMENTS	**8**
THE DRIVER	**8**
WELDING THE DRIVER	**9**
TROUBLE SHOOTING	
HINTS AND TIPS	**10-12**
NOTES	**13**

1. INTRODUCTION

The Bulroc ***CDS310R*** Overburden System is a concentric drilling system designed to simultaneously case a hole through loose overburden conditions down into the solid bedrock.

This system has a multi-stage-cutting head to guarantee the drilled hole is straight with minimum deviation. The independent segments around the periphery of the head give equal concentric cutting forces resulting in fast, low torque drilling.

Since “down time” is very costly, this system is designed to require the minimum amount of maintenance. However when parts do eventually wear, the construction of the system is such that the areas of the cutting head which experience most wear, can be replaced independent of the slower wearing areas and so minimise operating costs.

ALWAYS THINK SAFETY FIRST!

This manual is published by and copyright © of Bulroc (UK) Ltd. All Rights Reserved. Always operate your Bulroc drilling equipment according to the instructions contained within this operating manual. Further copies of this manual can be downloaded from the Bulroc website; **www.bulroc.com**. For urgent support or sales enquiries, call Bulroc on **+44 (0)1246 544700** or Skype **BULROCUKSALES .** E & O.E

2. USING THE CDS310R

Drill Rigs :-

Drill rigs on which the ***CDS310R*** is to be used should have a feed length at least one metre more than the longest casing. This will allow sufficient clearance for any adapters or drive subs required by the system.

Drill Tubes :-

Standard Hexagon Drive Drill rods used with the system may require sleeves fitting over their entire length. This would be necessary to effectively reduce the annulus area between the drill pipe and the I/D of the casing so as to increase the "up hole velocity" for efficient removal of the drill cuttings and also prevent blockages occurring inside the casing. As a general guide the sleeve diameter should be 4" smaller than the bore of the casing, but the exact size can be calculated by using the formula below. A figure of 3000ft/min (915m/min) should be used as a minimum for the required velocity.

Hammer :-

In certain circumstances it may be necessary to sleeve the hammer. This sleeve however should be a split bolt together type, not welded. The outer diameter of this sleeve should be the same as the diameter of the drill tube sleeves. The formula below is for calculating the correct diameter of sleeves for the hammer and drill rods:

UP HOLE VELOCITY FORMULA (METRIC)

$$VM = \frac{Y(CFM) \times 1305096}{DM^2 - dm^2}$$

VM = Velocity in m / min
Y = Volume of air passed by Hammer at the selected pressure.
m3/min
DM^2 = Diameter of casing bore squared (in mm)
Dm^2 = Diameter of tube sleeve squared (in mm)

UP HOLE VELOCITY FORMULA (IMPERIAL)

$$VF = \frac{Y(CFM) \times 183.4}{Dl^2 - di^2}$$

VF = Velocity in feet / min
Y = Volume of air passed by Hammer at the selected pressure.
Ft^3/min
Dl^2 = Diameter of casing bore- squared (in inches)
Di^2 = Diameter of tube sleeve squared (in inches)

3. CALCULATING LENGTHS FOR STARTER CASINGS



The above diagram shows the length of starter casing required when using standard CDS equipment with the Bulroc HYPER 101 hammer. If an alternative hammer is to be used, the starter casing length can be calculated by either adding or subtracting the difference in effective length of the alternative hammer from that of the HYPER 101 hammer.

If hexagon type drill rods are used then an adaptor will need to be fitted between the Hammer and the first Drill Rod. To make sure the Starter Casing finishes in the correct position, just below the spanner flats on the Adaptor, its length will need increasing from that shown on the diagram.



SYSTEM PARAMETERS



CASING SHOE

4. CDS310R PARTS LIST



COMPONENT PARTS		
Ref.	**Description**	**Part No.**
1	Driver (SD10)	CDS310DH046R
1a	Driver (N100)	CDS310DH053R
2	Ring Bit	CDS310RRING
3	Solid Retaining Pin	CDS310RRP
4	Seloc Pin Set	CDS310RSP
5	Segments (3)	CDS310RSEG
6	Foot Valve (SD10)	BBF046
6a	Foot Valve (N100)	BBF053
QUICK ORDER CODES	**Complete System**	**CDS310046R SD10**
		CDS310053R N100

5. CDS310R SERVICING

The ***CDS 310R*** system is designed to require the minimum amount of service and maintenance. However, it is recommended that the system be stripped down every 500 metres and all the component parts checked for wear or damage.

Eventually the segments will need to be replaced and most likely, the buttons on the ring bit will require re-grinding. At this time, the following procedures must be followed:-

1. First remove both the Retaining Pin (4) and Seloc Pins (3) by first grinding away the tack weld at the front of the pin hole. Then using a punch from the opposite end of the Pin Hole Hammer out the Pins as shown.



2. Once the Pins are removed, rotate the Ring Bit anti-clockwise until it stops, then pull the Ring forward to remove.

3. The segments are now free to be withdrawn from their sockets.



6. CDS310R SERVICING (CONTINUED)

At this point, the segment bushes or sleeves can be examined.

These bushes are pressed into the driver to prevent wear whilst the segments are cutting and they are manufactured from hard, wear resistant steel that should outlast many segment changes before they will require replacing.

Before re-assembling the system, it is important to check the condition of the slots in the driver where the ring bit lugs locate. These slots may show some degree of wear and deformation and any signs of deformation must be removed using a small pencil grinder or similar to ensure correct location and drive of the ring bit. *This is particularly important if a NEW ring bit is being fitted to a WORN driver.*

Re-assembly Instructions

To re-assemble the system insert the new or re-sharpened segments into their sockets and slide the new or refurbished drive ring onto the driver and rotate clockwise until it stops.



SELOC PIN SET



RETAINING PIN

Now insert a NEW retaining pin and gently drive home with the punch before finally inserting a new Seloc Pins. Finally ensure a spot of tack weld is applied to secure the Pins in position so they cannot come out.

Recommendations for refurbishing worn components are given in page 8

7. HOW THE SYSTEM WORKS



The Bulroc ***CDS 310R*** overburden system is designed to enable the operator to drill and simultaneously case a hole through loose overburden ground conditions down into solid rock.
(*See diagram 1*)

After reaching the required depth, the segments can be moved into the closed position by pulling the system up against the casing shoe and counter rotating. If the hole has reached solid rock at its required depth, then the system can be closed by resting the system on the bottom of the hole and again, counter rotating. With the segments fully closed, the system can now be retracted through the casing leaving a clean, cased hole. (*See diagram 2*)

Should it be necessary to drill on further into the solid rock, the CDSR system can be detached from the Hammer and replaced with a conventional drill bit that can pass through the casing shoe. (*See diagram 3*)

The Bulroc CDSR overburden system simultaneously cases the hole by means of a shoulder on the driver. This shoulder locates against the top face of the casing shoe, which is welded into the starter casing. Since the casing does not rotate with the drill tubes, the torsional loads are relatively low and so either left hand threaded or welded casing can be used.

8. REFURBISHING WORN EQUIPMENT

The Ring bit and Segments

The most frequent cause of button failure can be attributed to over drilling and incorrect button regrinding. Regrinding at regular intervals, with the correct equipment, not only improves component life but also improves production and reduced overall drilling costs.

- Buttons should be reground to their original shape when the wear flat is 1/3rd the diameter of the button.
- If the button is cracked or chipped, it should be ground back flush to the steel matrix. It is possible to carry on drilling with a number of broken buttons if they are ground back in this way, providing they are not affecting the gauge diameter, or are not adjacent to each other since this would affect the smooth rotation of the bit.
- After regrinding check the protrusion heights of the buttons. If a button protrudes too far from the steel body it will cause premature failure of the button. The side protection buttons should be ground back flush with the body. The gauge buttons should be ground back until their protrusion height is ½ their diameter.

To perform the task of regrinding correctly, we recommend the use of a hand held grinder with gravity fed water supply necessary to cool the impregnated diamond grinding cups.

A combo type grinding cup of the approximate diameter will remove the surrounding steel matrix and reform the carbide button at the same time.

The Driver

The shoulder on the driver where it contacts against the casing shoe will eventually wear. This is quite normal and to be expected. However, when the drive shoulder does become worn to a taper shape, it will begin to jam in the casing shoe.

At this point, it will be necessary to re-form the drive shoulder back to its original 90 degree angle by welding up this area of the original shoulder. It is important that the following procedures are strictly followed to avoid damage and cracking of the driver.

9. WELDING THE DRIVER

Welding Procedures

- The bit holder **must** be preheated to between 200°C and 250°C before any welding takes place.
- This temperature must be maintained throughout the welding process - check temperature frequently using temp sticks.
- The weld must be applied in single runs around the shoulder area building it up to as near the original shape as possible.

Use 1mm CARBOFIL CRM01. AWSAS.28ER 80S/g or equivalent.



- After welding the holder must be slow cooled. This can be achieved by either burying the holder in a tank of vermiculite or similar, or by wrapping it in an asbestos blanket. This slow cooling is a very important part of the process. Rapid cooling can cause cracking.
- Once the holder has returned to room temperature it should be turned on a lathe back to its original shape.

Dimensions for turning are given in the table on page 3. The correct shape is important to avoid rapid wear of the casing shoes and subsequent wear of the bit holder.

If a lathe is not available then a small hand grinder can be used to reform the drive shoulder. Great care must be taken to get the surface even, and correctly form the 90 degree shoulder, if the surface is uneven and the angle incorrect it will lead to premature wear and jamming.

10. HINTS AND TIPS

Always Do the Following

- Make sure the Driver will pass through all the lengths of casing intended for the job. If the casing is to be welded, extra clearance should be allowed for weld spots, which may break through into the inside of the casing.

- If the casing is to be welded then the ends should be bevelled at an angle between 45 and 60 degrees. To prevent weld breaking through, and to help alignment, a 3mm wide land should be left on each end face.

If the casing is the threaded type, then it must be left hand. Because of the cost of the thicker walled casing required to produce a thread, it is normal practice to have threaded joints welded on to the end of thinner casing, thus keeping the cost to a minimum. If this is the case then great care must be taken to ensure the joints are true and concentric to the casing. An out of line joint can result in either the system jamming inside the casing, or the casing jamming in the hole. As with welded casing, the joints should have bevelled end faces to prevent weld breaking through into the inside of the casing.

- Check the casing shoes before the job starts. The inside diameter of the shoe should be within the following tolerances.

CDS 310R	
Minimum mm	**311.5**
Maximum mm	313

- Check the length of the casing shoes. When in position against the drive shoulder on the driver there should be between 12mm and 25mm clearance between the back faceof the segments and the front face of the casing shoe - depending on the size of the system. This distance will increase as the drive shoulder and/or the casing shoe wears.

- Make sure the segments swing from open, to closed position freely by hand.

- Use the diagram on page 3 to make sure the correct length of starter casing has been calculated.

- When drilling commences, use slow forward rotation. If jamming occurs, ease back on the feed force or lift the CDS and the casing until rotation starts again. Initially, the casing may rotate but after drilling down the casing 1-2 meters, it will stop rotating.

- Apply only light feed and reduced air pressure when setting the first casing and make sure the casing stays in line with the drill mast.

- When drilling through soft materials (sand, clays etc.) frequently lift the CDS and the casing a little to ensure that it is loose and to flush out any debris from the casing. When the CDS is in the "hang position", all available air will go to directly flushing the casing. In sand and gravels, it is often preferable to reduce air and feed pressure to a minimum.

11. HINTS AND TIPS (CONTINUED)

- When drilling in sticky, plastic clay, the addition of water or even foaming agents in the hammer air may be necessary to maintain good flushing.

- When drilling through boulders or inclined rock faces the fact that this concentric system has a number of independently operating segments. With a concentric system the independent segments only require a very small amount of movement to travel from the open to closed position, this is somewhere in the region of 20 to 30 degrees rotation of the system. Consequently if you attempt to hammer without rotation then the segments will swing back into the closed position causing the system to produce a socket in the rock that is only the diameter of the pilot bit. So once rotation is resumed the segments cannot open back out as they are retained by the sides of the rock socket.

To prevent this occurring a concentric system should have its RPM increased and feed rate reduced, once it starts to encounter boulders or inclined rock. By doing this you guarantee that the segments remain in the open position even if their contact with the rock is intermittent. The system should then be fed slowly into the boulder, or rock face, until continuous cutting can be heard. At no time must the rotation be stopped whilst hammering is taking place. If at any point the system starts to jam against the inclined face it must be immediately pulled back and then slowly fed forward back into the rock.

Once the system has formed a complete socket in the rock the speed and feed can be reduced back to the correct rates suitable to the type of rock being drilled. The segments on this concentric system should be much easier to move from open to closed position and consequently the most important consideration when using a concentric system is to maintain clockwise rotation throughout the entire drilling cycle. The only time reverse rotation should be applied is when you wish to close the segments, and at no time should the system be hammered without rotation as this will either allow the segments to vibrate back into a closed position, or if this doesn't happen then the segments will form three sockets in the rock that could generate extremely high torque loads once rotation was re-applied.

- When the casing has been set to the required depth, and when drilling in sticky ground, care must be taken to clean out the inside of the casing before extracting the drillstring. Water poured inside the casing repeatedly and flushed out will help the process. On occasions it may be necessary to pull the CDS system back into the casing to flush out blockages. To perform this task the system should be lifted into the "hang" position and rotated clockwise for 2 or 3 revolutions to ensure the bit face is clean. The system should then be pulled back against the casing shoe and the air turned off. At this point the rod should be marked to give a reference point for when the system is fed back through the shoe. Reverse rotation for 1 revolution will then close the segments and allow the system to be pulled back into the casing. Once inside, the air can be turned back on and the system should then be moved up and down inside the casing until the blockage is cleared. At no time must the system be rotated whilst it is inside the casing as this will cause the segments to jam against the casing wall.

12.HINTS AND TIPS (CONTINUED)

When the casing is clean the system should be fed back through the shoe using the reference point on the rod to indicate when it is through the shoe. Once through the shoe the system can be rotated clockwise to open out the segments.

- Always re-grind worn buttons.

Never do the Following

- Penetrate too fast in loose ground. Overfeeding will "bury" the CDS and block the casing with nowhere for the hammer air to exhaust, hence stopping the hammer. Always give the flushing air a chance to bail out the debris and keep the casing clear.
- Over rotate. This will lead to premature button wear. In rock or boulders, rotation of the ***CDS310R*** should be between 10 to 12 rpm. In loose ground conditions this can be increased by 50%.
- Apply weld to either the ring bit (apart from a small tack weld at the start of the pin hole), or the segments. This can lead to cracking and button failure. No warranty can be considered on these parts if there is any evidence of welding.

13. NOTES

This page is left intentionally blank

CDS-R

© 2013 Bulroc (UK) Ltd. All Rights Reserved.

Manufacturers of Rock Drilling Equipment

Turnoaks Business Park, Burley Close, Chesterfield ,Derbyshire S40 2UB
Tel: +44(0) 1246 544700 Fax: +44(0) 1246 544701
E-mail: info@bulroc.com website bulroc.com

CDS310R/100 17/09/13